

MAGICTEAM

White Noise Machine User Manual


Models: SN-A1, Sleep Sound Machine, White Noise Machine

This PDF was downloaded from <https://mymagicteam.com/>

Table of Contents

- Important Safety Information
- Product Overview & Models
- What's in the Box
- Product Specifications
- Getting Started
- Operating Instructions
- Sound Selection Guide
- Timer & Memory Functions
- Troubleshooting
- Care & Maintenance
- Warranty Information
- Contact Information

Important Safety Information

 **WARNING:** Please read all safety instructions before using this device.

- Do not expose the device to water, moisture, or extreme temperatures
- Use only the provided power adapter or USB cable
- Keep away from heat sources and direct sunlight
- Do not attempt to repair the device yourself
- Supervise children when using this device
- Do not use damaged power cords or adapters
- Unplug the device during thunderstorms or when not in use for extended periods
- Clean only with a dry cloth when unplugged

Product Overview & Models

Magicteam offers three main white noise machine models, each designed to provide superior sound therapy for better sleep and relaxation:

<p>Magicteam Sound Machine SN-A1</p> <p>Compact and effective solution featuring 20 non-looping natural sounds, 32 adjustable volume levels, and customizable timer settings. Perfect for home or travel use.</p>
<p>Magicteam Sleep Sound Machine</p> <p>Premium model with 40 non-looping sounds in elegant B-white design. Features memory function, 32 volume levels, and comes with 18-month warranty.</p>
<p>Magicteam White Noise Machine</p> <p>Classic model available in black, white, or wood finish. Features 20 non-looping sounds, 32 volume levels, and flexible timer options. Compact and portable design.</p>

Key Features (All Models)

- **Non-Looping Sounds:** Natural, seamless audio without repetitive patterns
- **32 Volume Levels:** Precise control for personalized sound experience
- **Memory Function:** Automatically saves your preferred settings
- **Timer Options:** 1-5 hour settings plus continuous play mode
- **Dual Power Options:** AC adapter and USB powered
- **Safety Certified:** FCC, CE, and RoHS compliant
- **Portable Design:** Compact and travel-friendly

What's in the Box

- 1x Magicteam White Noise Machine
- 1x AC Power Adapter
- 1x USB Cable
- 1x User Manual
- 1x Warranty Card

Product Specifications

Specification	Details
Sound Options	20-40 non-looping natural sounds (model dependent)
Volume Levels	32 adjustable levels
Timer Settings	1, 2, 3, 4, 5 hours + Continuous play
Power Input	DC 5V/1A via AC adapter or USB
Dimensions	Approximately 4.1" × 4.1" × 2.2"
Weight	Approximately 1.2 lbs
Material	ABS plastic housing
Certifications	FCC, CE, RoHS
Warranty	18 months (Sleep Sound Machine), 12 months (other models)

Getting Started

Initial Setup

- 1 Power Connection:** Connect the AC adapter to the device and plug into a wall outlet, or use the USB cable to connect to a USB port.
- 2 First Power On:** Press and hold the power button for 2 seconds to turn on the device. The LED indicators will illuminate.
- 3 Initial Volume Setting:** The device will start at a moderate volume level. Use the volume controls to adjust to your preference.

Operating Instructions

Control Panel Layout

Your Magictream device features intuitive button controls:

- **Power/Timer Button:** Power on/off and timer selection
- **Sound Selection Buttons:** Navigate through available sounds
- **Volume Up/Down:** Adjust volume across 32 levels
- **LED Indicators:** Show timer status and power state

Basic Operation

- 1 Power On:** Press the power button once. The device will turn on with the last used settings (if memory function is available).
- 2 Select Sound:** Press the sound selection buttons to cycle through available sounds. Each press advances to the next sound option.
- 3 Adjust Volume:** Use the volume up/down buttons to find your preferred level. The device offers 32 precise volume levels for optimal customization.
- 4 Set Timer:** Press the timer button to cycle through timer options (1, 2, 3, 4, 5 hours, or continuous). LED lights indicate the selected timer duration.
- 5 Power Off:** Press and hold the power button for 2 seconds to turn off the device.

Sound Selection Guide

Your Magictream device includes a variety of non-looping natural sounds designed for different preferences:

White Noise Variations

- **Classic White Noise:** Full spectrum sound for masking disruptions
- **Pink Noise:** Balanced frequency for deeper sleep
- **Brown Noise:** Deep, rumbling sound for relaxation

Nature Sounds

- **Rain Sounds:** Light rain, heavy rain, rain on leaves
- **Ocean Waves:** Gentle waves, rolling surf
- **Forest Sounds:** Birds chirping, wind through trees
- **Water Sounds:** Flowing stream, waterfall

Ambient Sounds

- **Fan Sounds:** Various fan speeds and types
- **Mechanical Sounds:** Air conditioner, vacuum cleaner
- **Lullabies:** Gentle melodies for babies and children

Timer & Memory Functions

Timer Operation

The timer function allows you to set automatic shut-off times:

- **1-5 Hour Settings:** Press the timer button to cycle through 1, 2, 3, 4, or 5-hour durations
- **LED Indicators:** The number of lit blue LEDs corresponds to the timer duration (1 LED = 1 hour, 2 LEDs = 2 hours, etc.)
- **Continuous Play:** When all LEDs are off, the device will play continuously until manually turned off
- **Fade-out Feature:** The volume gradually decreases over the last few minutes of the timer period

Memory Function

Available on select models, the memory function automatically saves your preferences:

- **Auto-Save:** The device remembers your last used volume, sound, and timer settings
- **Quick Start:** When powered on, the device returns to your previous configuration
- **Power-Off Memory:** Settings are retained even when unplugged

Troubleshooting

Problem: Device won't turn on

Solutions:

- Check power connection and ensure adapter is properly plugged in
- Try using USB power instead of AC adapter
- Press and hold power button for 3-5 seconds
- Check that power outlet is working

Problem: No sound output

Solutions:

- Check volume level - press volume up button
- Ensure a sound is selected
- Verify device is not in timer countdown mode
- Try selecting a different sound

Problem: Sound quality issues

Solutions:

- Clean the speaker area with a dry cloth
- Ensure device is on a stable, flat surface
- Check for interference from other electronic devices
- Try adjusting volume to optimal level

Problem: Timer not working properly

Solutions:

- Press timer button multiple times to cycle through settings
- Ensure LEDs are indicating correct timer duration

- Power cycle the device and reset timer
- Check if device is set to continuous play mode

Care & Maintenance

Cleaning Instructions

- Always unplug the device before cleaning
- Use only a dry, lint-free cloth to clean the exterior
- Do not use water, liquids, or cleaning chemicals
- Clean speaker grilles gently with a soft brush if needed
- Avoid getting moisture in any openings

Storage Guidelines

- Store in a cool, dry place when not in use
- Avoid extreme temperatures and humidity
- Wrap power cord loosely to prevent damage
- Use original packaging for long-term storage

Optimal Performance Tips

- Place device on a stable, flat surface
- Maintain adequate ventilation around the device
- Keep away from direct sunlight and heat sources
- Regularly check power connections for security
- Update settings periodically to maintain memory function

Warranty Information

Warranty Coverage

- **Sleep Sound Machine:** 18-month limited warranty
- **Other Models:** 12-month limited warranty
- **Coverage:** Manufacturing defects and material failures
- **Exclusions:** Damage from misuse, accidents, or normal wear

Warranty Claims

To make a warranty claim:

1. Contact Magicteam customer support
2. Provide proof of purchase and serial number
3. Describe the issue in detail
4. Follow provided troubleshooting steps
5. Arrange for repair or replacement if necessary

Contact Information

Customer Support

- **Website:** <https://mymagicteam.com/>
- **Product Support:** Available through official website
- **Response Time:** Within 24-48 hours
- **Support Hours:** Monday - Friday, Business Hours

Additional Resources

- Product registration available on official website
- FAQ section with common questions and solutions
- Video tutorials and setup guides
- Customer reviews and testimonials
- Software updates and announcements

Magicteam White Noise Machine User Manual

Downloaded from: <https://mymagicteam.com/>

© 2025 Magicteam. All rights reserved.

FCC, CE, and RoHS Certified | Made with quality and care

For the most up-to-date information, please visit our official website.